

# WIRING DIAGRAMS

## Fig. 1: Engine Compartment

### 1988 BMW 750iL

For DIAKOM-AUTO <http://www.diakom.ru> Taganrog support@diakom.ru (8634)315187  
 Copyright © 1998 Mitchell Repair Information Company, LLC  
 Friday, November 03, 2000 05:04PM

**COMPONENT LOCATOR:**

A/C CTRL UNIT	.....	C 28-31
A/C RELAY	.....	D 32
A/C SW	.....	A-E 34-35
A/T RANGE SW	.....	C-D 51
ABS CTRL UNIT	.....	A-B 20
ABS HYDRAULIC UNIT	.....	A-C 23
ABS RELAY	.....	A 23
ALTERNATOR	.....	D 3
ANTENNA AMP	.....	A 70
ANTI-THEFT MOD	.....	A-B 52
AUX RLY BOX	.....	D 15
BATTERY	.....	A 2
BLOWER MOTOR	.....	E 30
BLOWER RELAY	.....	C 12
CIG LTFS	.....	E 59
CHECK CTRL MOD	.....	A-C 44
CHIME MOD	.....	E 56
COMB SW	.....	C-D 36
COMP CLUTCH	.....	D 32
COMP CTRL RLY	.....	B 32
CRASH CTRL UNIT	.....	E 36
CRUISE CTRL MOD	.....	D-E 40
CRUISE CTRL SW	.....	C-D 40
DIAGNOSTIC CONN	.....	C 4
DIAGNOSTIC MOD (SRS)	.....	E 47
DIMMER	.....	B 39
DIR LIGHT RLY	.....	D 36
DOME LT/MP READING ASSY	.....	D 59
DOOR LOCK SWS	.....	C-D 52
DOOR SWS	.....	B 47
DRIVERS MEMORY SEAT	.....	A 60-62
ADJ SWITCH	.....	B 66-67
DRIVERS SEAT HEATER SW	.....	B 60
DRIVERS THIGH SUPPORT SW	.....	A 16
E-BOX FAN	.....	C-D 23
EDC CTRL UNIT	.....	E 23
EDC SW	.....	C-E 20
ETC	.....	E 29
FINAL STAGE UNIT	.....	D 12
FLASHLIGHT CHARGING PLUG	.....	B-D 8-13
FNT DEFOG/WATER PUMP RLY	.....	B 66-67
FNT PWR DISTRIBUTION BOX	.....	B 36
(FNT PDB)	.....	C-D 56
FNT PWR WCD SWS	.....	D 4
FOG LT SW	.....	A-E 55
FOOTWELL LTS	.....	D 56
FUEL PUMP	.....	B-C 36
FUEL PUMP RLY	.....	D-E 36
GENERAL MOD	.....	A-B 40
GLOVE BOX LT	.....	A-B 33
HAZARD SW	.....	E 32
HAZARD FLASHER RLY	.....	A 11
HEADLT/FNT DEFOG LT MOD	.....	B 7
HEATER/VENT RLY	.....	D-E 8
HIGH SPEED RLY	.....	A-E 48-49
HORN RELAY	.....	C 11
IGNITION COIL	.....	D 13
IGNITION SW	.....	D 13
INST CLSTR	.....	A 4
K9 UNLOADER RLY	.....	A 64-66
K9 UNLOADER RLY	.....	D 84
LEFT REAR SEAT POSTN/HTR RLY	.....	D 64
LIGHT CTRL MODULE	.....	D-E 38
LIGHT SW	.....	E 52-55
LOCK MOTORS	.....	C 7
MAIN RELAY	.....	D 60-63
MEMORY SEAT/MIRROR	.....	D 63
CTRL UNIT	.....	D 68
MEMORY SEAT/MIRROR SW	.....	A 4,7
MIRROR CTRL SW	.....	D 32-34
MOTRONIC CTRL UNIT (MCU)	.....	C-E 44
NORMAL SPEED	.....	B-C 39
ON BOARD COMPUTER (OBC)	.....	A 86-87
PARK LIGHT RLY	.....	E 21-22
PASS THIGH SUPPORT SW	.....	B-C 68
POWER ASSIST STEERING	.....	D 22
SERVOTRONIC	.....	D 23
POWER MIRROR MOTOR	.....	D 18
PROGRAM SW	.....	A-E 17-19
PUMP RLY	.....	D-E 59
REAR DEFOG RLY	.....	D-E 57
REAR PWR DISTRIBUTION BOX	.....	A-B 59
(REAR PDB)	.....	B-D 24-27
REAR READING LTS (RT/LEFT)	.....	A 64-66
REAR SEAT HEATER SW	.....	D 84
REAR WCD SWS	.....	E 46
RELAY MODULE	.....	C 3
RT FNT SEAT CTRL SW	.....	D 2
RT REAR SEAT HTR RLY	.....	C 36
SAFETY SW	.....	A 68
STARTER MOTOR	.....	E 30
STARTER RELAY	.....	E 7
STOP LT SW	.....	E 30
SUNROOF POSTN SW	.....	E 7
TEMP DISTRIBUTION POT	.....	E 30
THROTTLE SW	.....	E 7
TRANSCIVER	.....	E 7
TRUNK COMP LT	.....	D 70
TRUNK LT SW	.....	E 70
TRUNK MOTOR	.....	E 55
TRUNK LOCK SW	.....	A 54
UNDERHOOD LIGHT	.....	E 3
VANITY MIRROR LT	.....	B-C 70
VALVE RELAY	.....	A 70
WASHER JET HTR	.....	A 42
WASHER PUMP RLY	.....	A 43
WATER VALVE ASSY	.....	A 32
WINDOW LIMIT SWS	.....	A 57
WINDOW MOTORS	.....	B-C 59
WIPER MOTOR	.....	D-E 41
WIPER PRES CTRL MTR	.....	A 41
WIPER PRES CTRL RLY	.....	A-B 43
WIPER RELAY	.....	D 41
WIPER/WASHER SW	.....	D-E 43

